

## **UNO4 and UNO8 Zone Expander Connection Instructions**

Please visit <u>www.eyezon.com/guides</u> for more information about using these 2 modules with a **Universal** or **Stand-Alone** EVL4 or DUO system or using the UNO8 with an **UNO IP Panel**.

Use the supplied cables and jumpers to set the expanders as required.

